




Trench shoring - Shoring

Pile Chamber

Pile chambers are the first choice where supply lines are crossing

Av. Olivos 3193 (B1615BLG), Panamericana Ramal Pilar (Km 35) - Buenos Aires, Argentina.
Phone: (+54) 2320-628928 / atenko@atenko.com / www.atenko.com.ar